



# Air heaters D 1 L E

Troubleshooting and Repair Manual

© Eberspächer

© Eberspächer  
Eberspächer AG  
Postfach 100 000  
72074 Stuttgart  
Germany  
www.eberspaecher.com

The Troubleshooting and Repair Manual is valid for the following heater versions:

## D 1 L E

25 1 750 05 00 00 – 12 V


25 1 701 05 00 00 – 24 V

## Contents

## Page

Sectional view .....	2
Description of operation .....	3
• The control system • First check the following points .....	3
Wiring diagram .....	5, 6
Repair instructions .....	6-11
Measuring the fuel quantity .....	12
Check heater and components .....	13

Sectional view



**Parts list**

- |                                |                               |                    |                  |
|--------------------------------|-------------------------------|--------------------|------------------|
| 1 Heating air blower wheel     | 8 Heat exchanger              | 14 Exhaust hose    | F Fresh air      |
| 2 PCB with control unit        | 9 Outer jacket                | 15 Fuel motor pump | V combustion air |
| 3 Combustion air blower wheel  | 12 Flange seal                | 16 Fuel filter     | S = fuel         |
| 4 Glow plug                    | 11 Fuel line                  | 17 Main fuse 25 A  | W Intake         |
| 5 Safety thermal cutout switch | 12 Blower motor               | 18 ON/OFF switch   | A exhaust        |
| 6 Combustion chamber           | 13 Combustion air intake hose | 19 Timer           |                  |
| 7 Flame sensor                 |                               | 20 Millimeter      |                  |



## Description of operation/operating instructions

### Control elements

- On/Off switch
- Master timer (optional part, optional, see p. 28). The timers can be used to select the heater on or off during the timer, or to preset the switch-on time.

### Mode of operation

Procedure after switch-on:

**Switch-on:** Set On/Off switch to "ON".  
The pilot light in the On/Off switch goes on.

Further procedures (optional):  
 after fuel flow: Blower 10m  
 Master timer (optional part): 10m  
 After about 25 sec: Fuel flow 10m  
 When a stable flame has been obtained: Glow plug off

The water is preheated at a heating capacity of 1600 W, and the air heated by the heater through a panel. The resulting air is fed into the space to be heated.

**Switch-off:** Set On/Off switch to "OFF".  
The pilot light goes off.

The blower continues to operate to cool the water and slowly shuts down automatically after about 3 minutes.

### Controls and safety equipment

The flame cut-offter for the flame sensor (1), and the max. permissible temperature by the safety thermal limit switch (2).

Both affect the electronic control unit, which shuts down the burner in the event of fault.

1. If the burner fails to ignite within 180 seconds of the start of fuel pump operation, the flame sensor (1) will shut off operation. A fault shutdown takes place, with the burner unable to continue to operate for about 3 minutes. After the glow plug is set to "ON" during the first 30 seconds, the fault shutdown can be cancelled by waiting 30 seconds then looking.

2. In the event of overheating of the burner, thermal cut-off switch (2) is operated, the fuel supply is interrupted, and fuel shut-down follows with the blower motor continuing to operate, as described above.

Once the cause of the overheating has been removed, the burner can be restarted by switching "off" and then re-igniting.

3. If during start-up operation, a start or fault or interrupt or occurs in glow plug, the starting pump will turn on immediately, but will shut down after about 30 seconds with the blower motor continuing to operate as described above.

4. The operation of the blower motor will not stop if a supply of air fails to start or if the master speed is below the minimum value, but a shutdown takes place.

5. When the heater is switched off, the glow plug is switched on during the glow plug shutdown for about 30 seconds after glow to clear the combustion chamber.

The heater must always be switched off when the tank is empty.

The heater must not be operated in gauges.

### In the event of trouble, first check the following:


- Fuel in the tank?
- When changing over to winter operation:  
 Is there still summer quality diesel oil in the tank?  
 Fuses OK?
- Electrical free and connections OK?
- Compressor air and exhaust piping systems free?


When compressor produces soot, check the following:  
 Compressor air and exhaust piping systems clogged?  
 Remove cause of clogging.

Fuel metering pump delivery (air intake) or too low?  
 Measure fuel quantity (making fuel metering pump if necessary). Clean the fuel stopcock (strainer) in the metering pump.

Deposit in heat exchanger?  
 Clean heat exchanger, or replace if necessary.

Wiring diagram






- |    |         |    |          |
|----|---------|----|----------|
| r  | = red   | gr | = green  |
| br | = brown | ge | = yellow |
| wh | = white | gr | = grey   |
| sw | = black | lx | = blue   |

#### Parts list

- |       |  |
|-------|--|
| 1.1   | Flame monitor  |
| 1.2   | 16A plug   |
| 1.5   | Safety thermal cut-off switch                                  |
| 1.7   | RCB with control unit  |
| 1.12  | Flame monitor  |
| 2.2   | Fuel metering pump   |
| 2.7   | Main fuse 25 A   |
| 2.15  | Sensor, external temperature                                   |
| 3.1.1 | Heating switch continuous operation                            |
| 3.2.5 | Timer  |
| 3.3.6 | Timer  |
| 3.4.5 | Switch on pilot light  |
| 4.1   | Boiler   |
| a1    | test terminal, digital timer (not in use in this boiler model) |
| b1    | terminal 15  |
| c1    | lighting terminal 33   |
| o1    | optional   |



Parts list

- 1. Combustion air blower
- 2. Base
- 4. Air filter (with pre-filtering print, a spare part)
- 5. Sealing ring
- 6. Sealing washer

- 9. Heat exchanger
- 10. Cable line for safety thermal cut-off switch
- 11. Safety thermal cut-off switch
- 12. Cap

- 13. Handle sensor with cord line
- 15. Retaining spring
- 16. Plug
- 17. Glow plug
- 19. Upper casting half

- 20. Cable harness
- 21. Cap
- 22. Lower casting half
- 23. Cap
- 24. Air filter section
- 25. PCB with motor's unit



## Repair steps

1. Removing/fitting the glow plug
2. Removing/fitting the plug filter
3. Removing/fitting the PCB with control unit
4. Removing/fitting the air outlet section
5. Removing/fitting the upper casing half
6. Removing/fitting the safety thermal cutout switch
7. Removing/fitting the flame sensor
8. Removing the blower from the heat exchanger  
Changing the seals on the heat exchanger
9. Changing the seals on the blower

### 1. Removing/fitting the glow plug

Unscrew cap,  
Detach glow plug connector,  
Unscrew glow plug.



### 2. Removing/fitting the plug filter


Remove the plug filter from the plug connection  
using pliers.

When putting the plug filter back in, ensure correct  
positioning of the lug.

Carefully slide in the plug filter as far as it will go.




Installation position of plug filter in D 1 L E



### 3. Removing/fitting the PCB with control unit

Detach plug from the PCB.  
Press down the lug.  
Pull out the PCB.



Protect the PCB with control unit from static discharge:

- only use in garages
- avoid surfaces with plastic coating
- prevent yourself from becoming statically charged or, if so, contact earth to ensure discharge.



### 4. Removing the air outlet section









### 5. Removing/fitting the upper casing half


To remove the body-bound rivet, knock the pin through with a small drift.  
Prise out the rivet with a knife.

Use a new rivet for reassembly.




Remove the upper casing half


### 6. Removing the safety thermal cutout switch




Fit the safety thermal cutout switch, using new clamping springs.



7. Removing the flame sensor




Fitting the flame sensor



1 spacer clamps for the casing halves

#### Removed parts


- 1 PCB with control unit
- 2 Safety thermal cutout switch
- 3 Glow plug
- 4 Plug filter
- 5 Flame sensor






### 8. Unscrewing the blower from the heat exchanger

Remove the blower



Change the seals on the heat exchanger.  
Unscrew the flange (1) from the heat exchanger.  
Fit new seals (2) and (3) as illustrated.



### 9. Replacing the seals on the blower

Remove/scrape the old seal from the blower flange.  
Affix new seal (self-adhesive).

**Note:**

When fitting the combustion air blower/heat exchanger into the lower casing half, care must be taken that the fastening hooks of the blower engage in the slots of the casing half, otherwise the blower wheel might catch.



## Measuring the fuel quantity

**IMPORTANT!** Only measure the fuel quantity when the battery is fully charged. A load of 11/22 W and max. 13.26 V should be applied at the control unit during measurement.

### 1. Preparation

Remove electrode from glow plug. Caution: Do not use fuel ground (fuel) in the fuel line, nor the battery and place in a measuring glass (15 or 20 cm diameter). Note: Fuel is 0.8 g/ml. The 12 pin plug terminals 8 & 9 are used for the electrode unit. Switch on the heater. After approx. 60 seconds the metering pump starts to pump fuel. When the fuel is coming out smoothly and free of bubbles, the fueling is finished.

Switch off the heater and empty the measuring glass.

### 2. Measurement

Switch on the heater

Fuel to be pumped approx. 90 cc/s after switching on. Hold the measuring glass at the plug level during measurement. Read off the volume of the fuel meter.

Fuel pumping stops automatically after 130 seconds.


Switch the heater off.

Read off the fuel quantity in the measuring glass.


### 3. Evaluation

Interpolate the values obtained by the graphs. The fuel flow is measured only when the immersion of the two lines is within the limit curves.

If the intersection is outside the limit curves, the metering pump must be isolated.



Connect collimeter to control unit





## Testing the heater and the components

Remove the PCB with the fire unit from the heater.

### 1. Testing the burner motor

Detach the 2-pin plug from the control unit (see sketch of PCB operating stage) in order to: The motor must stop at a normal

Speed: 4.500 rpm (n = 30%).

The motor speed must not be below the blow-off

### 2. Testing the safety thermal cutout switch

Detach the 2-pin plug from the control unit (see sketch of

PCB) in order to: Check the safety thermal cutout switch for conductivity using a test lamp or a multimeter.

### 3. Testing the flame sensor

Detach the 2-pin plug from the control unit (see sketch of PCB) in order to: Connect an ohmmeter.

Resistance value: 200 to 1.100 Ω, with and without

gas to 20-30 Ω, with the heater, the gas is off.

PCB with the parts (unit)

