



# HYDRONIC D5WS

Fault Codes and Remedies

Eberspächer

EN

Eberspächer Climate  
Control Systems  
GmbH & Co. KG  
Eberspächerstr. 24  
73730 Esslingen  
Germany

[www.eberspaecher.com](http://www.eberspaecher.com)  
[info@eberpaecher.com](mailto:info@eberpaecher.com)


**The troubleshooting and repair instructions are valid  
for the following engine-independent water heaters:**

## Heaters for petrol

	Order No.
B 4 W S FL – 12 volt	20 1852 01 00 00
B 5 W S – 12 volt	20 1819 01 00 00

## Heaters for diesel

	Order No.
D 4 W S FL – 12 volt	25 2355 01 00 00
D 5 W S – 12 volt	25 2217 01 00 00
D 5 W S – 24 volt	25 2218 05 00 00



## 4 Troubleshooting

Error code Display	Fault description	Explanations • Remedies
010	Overvoltage – shutdown	<p>Overvoltage at controller min. 20 seconds without interruption --&gt; HYDRONIC does not function.</p> <ul style="list-style-type: none"> <li>Disconnect connection B1/S1, start vehicle engine, measure voltage in connector B1 between chamber 1 (cable 2.5<sup>2</sup> red) and chamber 2 (cable 2.5<sup>2</sup> brown).</li> </ul> <p>If the voltage &gt; 15 / 32 volt, then check the dynamo regulator or battery.</p>
011	Undervoltage – shutdown	<p>Undervoltage at controller min. 20 seconds without interruption --&gt; HYDRONIC does not function.</p> <ul style="list-style-type: none"> <li>Disconnect connection B1/S1, vehicle engine is off, measure voltage in connector B1 between chamber 1 (cable 2.5<sup>2</sup> red) and chamber 2 (cable 2.5<sup>2</sup> brown).</li> </ul> <p>If voltage &lt; 10 / 20 volt, then check fuses, supply lines, ground connections and plus points on battery for loss of voltage (corrosion).</p>
012	Overheating (software – threshold value)	<p>Temperature at overheating sensor &gt; 125°C.</p> <ul style="list-style-type: none"> <li>Check water circuit; <ul style="list-style-type: none"> <li>– Check all hoses for any leaks</li> <li>– Is there a throttle in the water circuit?</li> <li>– Has the direction of flow been observed when installing thermostat and non-return valve?</li> <li>– Is the water circuit properly vented?</li> <li>– Check functions of water pump</li> </ul> </li> <li>Check temperature sensor and overheating sensor, replace if necessary – control values see page 36.</li> </ul>
014	Possible overheating detected (differential evaluation)	<p>Difference in temperature values of overheating sensor and temperature sensor &gt; 25 K.</p> <p>Prerequisite for this error code is that HYDRONIC is operating and the water temperature at the overheating sensor has reached min. 80°C.</p> <ul style="list-style-type: none"> <li>Check water circuit; <ul style="list-style-type: none"> <li>– Check all hoses for any leaks</li> <li>– Is there a throttle in the water circuit?</li> <li>– Has the direction of flow been observed when installing thermostat and non-return valve?</li> <li>– Is the water circuit properly vented?</li> <li>– Check functions of water pump</li> </ul> </li> <li>Check temperature sensor and overheating sensor, replace if necessary – control values see page 36.</li> </ul>
015	Operation lock – heater has overheated more than 10 times	<p>Controller is locked</p> <ul style="list-style-type: none"> <li>Unlock controller by deleting fault memory (see page 17 to 20).</li> <li>Check water circuit <ul style="list-style-type: none"> <li>– Check all hoses for any leaks</li> <li>– Is there a throttle in the water circuit?</li> <li>– Has the direction of flow been observed when installing thermostat and non-return valve?</li> <li>– Is the water circuit properly vented?</li> <li>– Check functions of water pump.</li> </ul> </li> </ul>



## 4 Troubleshooting

Error code Display	Fault description	Explanations • Remedies
017	Overheating detected – EMERGENCY OFF (hardware limit value)	<p>Temperature at overheating sensor &gt; 130°C.</p> <ul style="list-style-type: none"><li>Check water circuit:<ul style="list-style-type: none"><li>Check all hoses for any leaks.</li><li>Is there a throttle in the water circuit?</li><li>Has the direction of flow been observed when installing thermostat and non-return valve?</li><li>Is the water circuit properly vented?</li><li>Check functions of water pump.</li></ul></li><li>Check temperature sensor and overheating sensor, replace if necessary – control values see page 36.</li></ul>
020	Glow plug – interruption	<ul style="list-style-type: none"><li>Perform function test of glow plug in installed condition. To do so, unclip cable 1.5<sup>2</sup> white from chamber 9 of the 14-pole connector and cable 1.5<sup>2</sup> brown from chamber 12. Apply voltage of 8 / 18 V ± 0.1 V to the glow plug and measure current after 25 sec. The glow plug is OK with the following values; if the values differ, replace the glow plug. Glow plug 8 volt – current = 8.5 A      +1A -1,5A</li></ul>
021	Glow plug output: short circuit, overload or accidental ground	<p> <b>Caution</b></p> <p>In HYDRONIC 12 volt, perform the function test with max. 8 volt. In HYDRONIC 24 volt, perform the function test with max. 18 volt. Glow plug destroyed if voltage values exceeded.</p> <p>→ Ensure mains adapter is short-circuit proof.</p> <ul style="list-style-type: none"><li>If glow plus is OK, check glow plug lead for any signs of damage, check for current passage.</li></ul>
030	Speed of combustion fan motor outside tolerance range.	<p> <b>Caution</b></p> <p>In HYDRONIC 12 volt, perform the function test with max. 8.2 volt + 0.2 volt.</p> <p>In HYDRONIC 24 volt, perform the function test with max. 15 volt + 0.2 volt.</p> <p>Check that plus an minus leads are connected correctly.</p> <p>→ Ensure mains adapter is short-circuit proof.</p> <p>Fan impeller of combustion air fan motor blocked (frozen, dirty, stiff, lead chafes at end of shaft ...).</p> <ul style="list-style-type: none"><li>Remove blockage.</li><li>Measure speed of combustion air fan motor with max. 8.2 / 15 volt + 0.2 volt. To do so, unclip cable 0.75<sup>2</sup> brown from chamber 14 of 14-pole connector and cable 0.75<sup>2</sup> black from chamber 13.</li><li>Affix a marking to the shaft end of the combustion air fan motor and measure the speed with a contact-free speed counter (see page 33).</li><li>If the measured speed &lt; 10000 rpm, then replace the combustion air fan.</li><li>If the measured speed &gt; 10000 rpm, then replace the controller.</li></ul>
031	Combustion air motor – interruption	<p> <b>Caution</b></p> <p>In HYDRONIC 12 volt, perform the function test with max. 8.2 volt + 0.2 volt.</p> <p>In HYDRONIC 24 volt, perform the function test with max. 15 volt + 0.2 volt.</p> <p>Check that plus an minus leads are connected correctly.</p> <p>→ Ensure mains adapter is short-circuit proof.</p> <ul style="list-style-type: none"><li>Check that the cable harness of the combustion air fan motor is properly routed and check for any signs of damage.</li><li>Measure speed of combustion air fan motor with max. 8.2 / 15 volt + 0.2 volt. To do so, unclip cable 0.75<sup>2</sup> brown from chamber 14 of 14-pole connector and cable 0.75<sup>2</sup> black from chamber 13.</li><li>Affix a marking to the shaft end of the combustion air fan motor and measure the speed with a contact-free speed counter (see page 33).</li><li>If the measured speed &lt; 10000 rpm, then replace the combustion air fan.</li><li>If the measured speed &gt; 10000 rpm, then replace the controller.</li></ul>

## 4 Troubleshooting

Error code Display	Fault description	Explanations • Remedies
032	<p>Combustion air motor – short circuit, overload or accidental ground</p> <p> <b>Caution</b>            In HYDRONIC 12 volt, perform the function test with max. 8.2 volt + 0.2 volt.            In HYDRONIC 24 volt, perform the function test with max. 15 volt + 0.2 volt.            Check that plus an minus leads are connected correctly.  <b>→</b> Ensure mains adapter is short-circuit proof.</p>	<p>Fan impeller of combustion air fan motor blocked (frozen, dirty, stiff, lead chafes at end of shaft ...).</p> <ul style="list-style-type: none"> <li>• Remove blockage.</li> <li>• Before checking the functions of the combustion air fan motor, perform a resistance measurement between housing and lead. If the measured resistance &lt; 2 kΩ, then there is accidental ground. Replace the combustion air fan. If the measured value is &gt; 2 kΩ, then measure the speed of the combustion air fan motor.</li> <li>• Measure speed of combustion air fan motor with max. 8.2/ 15 volt + 0.2 volt. To do so, unclip cable 0.75<sup>2</sup> brown from chamber 14 of 14-pole connector and cable 0.75<sup>2</sup> black from chamber 13.            Affix a marking to the shaft end of the combustion air fan motor and measure the speed with a contact-free speed counter (see page 33).            If the measured speed &lt; 10000 rpm, then replace the combustion air fan.            If the measured speed &gt; 10000 rpm, then replace the controller.</li> </ul>
038	<p>Relay trigger of vehicle fan – interruption</p> <p><b>Please note</b>            This fault code is not displayed by all types of heaters.</p>	<ul style="list-style-type: none"> <li>• Check electric lead to relay, rectify interruption, replace relay if necessary.</li> </ul>
039	Relay trigger of vehicle fan – short circuit, overload or accidental ground	<ul style="list-style-type: none"> <li>• Pull relay off; if error code 038 is then shown, the relay is defect – replace relay.</li> </ul>
041	Water pump – interruption	<ul style="list-style-type: none"> <li>• Check lead to water pump for current passage. To do so, unclip cable 0.5<sup>2</sup> brown from chamber 10 of 14-pole connector and cable 0.5<sup>2</sup> from cable 11.            Rectify interruption, replace water pump if necessary.</li> </ul>
042	Water pump – short circuit, overload or accidental ground	<ul style="list-style-type: none"> <li>• Disconnect connection in water pump cable harness.            If error code 041 is then shown, the water pump is defect – replace water pump.</li> </ul>
047	Dosing pump – short circuit, overload or accidental ground	<ul style="list-style-type: none"> <li>• Disconnect connection in dosing pump cable harness.            If error code 048 is then shown, the dosing pump is defect – replace dosing pump.</li> </ul>
048	Dosing pump – interruption	<ul style="list-style-type: none"> <li>• Check dosing pump cable harness for current passage. Rectify interruption, replace dosing pump if necessary.</li> </ul>
050	Operation lock because of too many failed starting attempts (10 starting attempts, also start repetition for every starting attempt)	<p>Too many starting attempts, controller locked.</p> <ul style="list-style-type: none"> <li>• Unlock controller by deleting fault memory (see page 17 to 20).</li> <li>• Check fuel quantity and fuel supply, see page 37.</li> </ul>



## 4 Troubleshooting

Error code Display	Fault description	Explanations • Remedies
<b>051</b>	Time exceeded – blowing cold	At start, flame sensor reports temperature > 70°C for longer than 240°C. <ul style="list-style-type: none"><li>Check exhaust and combustion air guidance.</li><li>Check flame sensor – control values see page 32.</li></ul>
<b>052</b>	Safety time exceeded	<ul style="list-style-type: none"><li>Check exhaust and combustion air guidance.</li><li>Check fuel quantity and fuel supply, see page 37.</li><li>Clean or replace filter in dosing pump connection.</li></ul>
<b>053</b> <b>056</b>	Flame aborted from control stage “large” Flame aborted from control stage “small”	<b>Warning</b> After flame aborted from control stage “large” or “small” and after starting attempt within allowed number, HYDRONIC proceeds with a new start, where applicable with subsequent start repeat. If the new start or start repeat is successful, the error code is deleted. <b>Error</b> (because no more starting attempts allowed) <ul style="list-style-type: none"><li>Check exhaust and combustion air guidance.</li><li>Check fuel quantity and fuel supply, see page 37.</li><li>Check flame sensor, see error code 064 and 065.</li></ul>
<b>060</b>	Temperature sensor – interruption	<p><b>Please note</b></p> <p>The test with a bridge in the 14-pole connector can only be performed if HYDRONIC is still installed in the vehicle or if a test facility is available.</p> <ul style="list-style-type: none"><li>Remove controller and check connection lead of temperature sensor for any signs of damage. If the lead is OK, then short the temperature sensor: route the cable in the 14-pole connector from chamber 3 to chamber 4.</li><li>Switch HYDRONIC on:<ul style="list-style-type: none"><li>If error code 061 appears, then remove and check temperature sensor, see page 36.</li><li>If error code 060 still appears, then check and if necessary replace controller.</li></ul></li></ul>
<b>061</b>	Temperature sensor – short-circuit, overload or accidental ground	<p><b>Please note</b></p> <p>The test with a bridge in the 14-pole connector can only be performed if HYDRONIC is still installed in the vehicle or if a test facility is available.</p> <ul style="list-style-type: none"><li>Remove controller and check connection lead of temperature sensor for any signs of damage. If the lead is OK, then remove the 14-pole connector from controller, unclip cable 0.5<sup>2</sup> blue from chamber 3 and cable 0.5<sup>2</sup> blue from chamber 4.</li><li>Connect 14-pole connector to controller and switch HYDRONIC on:<ul style="list-style-type: none"><li>If error code 061 appears, then remove and check temperature sensor, see page 36.</li><li>If error code 061 appears, then check and if necessary replace controller.</li></ul></li></ul>
<b>064</b>	Flame sensor – interruption	<p><b>Please note</b></p> <p>The test with a bridge in the 14-pole connector can only be performed if HYDRONIC is still installed in the vehicle or if a test facility is available.</p> <ul style="list-style-type: none"><li>Remove controller and check connection lead of flame sensor for any signs of damage. If the lead is OK, then short the flame sensor: route the cable in the 14-pole connector from chamber 1 to chamber 2.</li><li>Switch HYDRONIC on:<ul style="list-style-type: none"><li>If error code 065 appears, then remove and check flame sensor, see page 34.</li><li>If error code 064 still appears, then check and if necessary replace controller.</li></ul></li></ul>

## 4 Troubleshooting

Error code Display	Fault description	Explanations • Remedies
<b>065</b>	Flame sensor – short-circuit, overload or accidental ground  <b>Please note</b> The test with a bridge in the 14-pole connector can only be performed if HYDRONIC is still installed in the vehicle or if a test facility is available.	<ul style="list-style-type: none"> <li>Remove controller and check connection lead of flame sensor for any signs of damage. If the lead is OK, then remove the 14-pole connector from controller, unclip cable 0.5<sup>2</sup> blue from chamber 1 and cable 0.5<sup>2</sup> brown from chamber 2. Connect 14-pole connector to controller and switch HYDRONIC on.             <ul style="list-style-type: none"> <li>If error code 064 appears, then remove and check flame sensor, see page 32.</li> <li>If error code 065 appears, then check and if necessary replace controller.</li> </ul> </li> </ul>
<b>071</b>	Overheating sensor – interruption  <b>Please note</b> The test with a bridge in the 14-pole connector can only be performed if HYDRONIC is still installed in the vehicle or if a test facility is available.	<ul style="list-style-type: none"> <li>Remove controller and check connection lead of overheating sensor for any signs of damage. If the lead is OK, then short the overheating sensor: route the cable in the 14-pole connector from chamber 5 to chamber 6. Switch HYDRONIC on:             <ul style="list-style-type: none"> <li>If error code 072 appears, then remove and check overheating sensor, see page 36.</li> <li>If error code 071 still appears, then check and if necessary replace controller.</li> </ul> </li> </ul>
<b>072</b>	Overheating sensor – short-circuit, overload or accidental ground  <b>Please note</b> The test with a bridge in the 14-pole connector can only be performed if HYDRONIC is still installed in the vehicle or if a test facility is available.	<ul style="list-style-type: none"> <li>Remove controller and check connection lead of overheating sensor for any signs of damage. If the lead is OK, then remove the 14-pole connector from controller, unclip cable 0.5<sup>2</sup> red from chamber 5 and cable 0.5<sup>2</sup> red from chamber 6. Connect 14-pole connector to controller and switch HYDRONIC on.             <ul style="list-style-type: none"> <li>If error code 071 appears, then remove and check overheating sensor, see page 36.</li> <li>If error code 072 appears, then check and if necessary replace controller.</li> </ul> </li> </ul>
<b>090</b> <b>092–103</b>	Controller defect	Replace controller.
<b>091</b>	External interference voltage	Error in controller from interference voltage from vehicle network, possible causes: poor batteries, poor battery chargers, other interference sources; eliminate interference voltages.

### Faults not shown by the diagnosis system

Fault description	Explanations • Remedies
HYDRONIC won't start	<p>After switching HYDRONIC on, the water pump and vehicle fan start immediately.</p> <ul style="list-style-type: none"> <li>Remove and check temperature sensor, see page 36.</li> </ul> <p>After switching HYDRONIC on, the vehicle fan starts, function "pre-venting" is activated.</p> <ul style="list-style-type: none"> <li>Changeover venting to heating at "heating / venting" changeover switch.</li> </ul>